

PROPANE GRILL LIGHTING INSTRUCTIONS

1. Ensure all burner knobs are in the OFF position. Connect the propane gas hose assembly and regulator to the cylinder and tighten the QCC1 inlet.
2. Open the propane cylinder valve and check all connection & hoses for leaks with a soap and water solution.
3. **CAUTION:** If hood is being used, open before attempting to light the grill.
4. Turn the crossover ignition burner control knob to the HI position. Press the igniter button several times and the burner should light. If the burner fails to light with igniter button, turn the gas off, and wait five (5) minutes. Turn on the gas and use a butane lighter or long match to light through the ignition hole in the right hand side of the grill body.
5. Once the crossover burner is lit, any main burner may be lit by simply turning the control knob for each burner to the HI position.

SHUT-DOWN

1. Close the cylinder valve and allow burners to burn the gas in the line and manifold.
2. Turn all the control valves to the OFF position.
3. Disconnect the grill hose assembly from the propane cylinder.

We **STRONGLY RECOMMEND** that you **ADD WATER** to **GREASE PAN** to **PREVENT COOKING FLARE UPS**. If you choose to **IGNORE THIS RECOMMENDATION** ABC's Party Time Rentals will not and can not be held responsible for damaged and/or **LOSS OF FOOD AND PROPERTY**. Any **DAMAGE TO THE UNIT** caused by flare ups can be at our discretion **CHARGED TO THE CUSTOMER**.

Although the customer **DOES NOT HAVE TO CLEAN** the Bar B Que, you are **RESPONSIBLE FOR EMPTYING** the **GREASE PANS** before the unit is transported.