

POPPA CORN COMPANY LTD.

220 Superior Blvd., Mississauga, Ontario L5T 2L2 Tel: (905) 564-2676 Fax: (905) 564-2374

E Q U I P M E N T R E N T A L

ECONO FLOSS MACHINE

Electrical Requirements:

This Econo Floss Machine is ready to plug into a 15 amp, 120 volt/60 cycle standard wall receptacle.

Operating Instructions:

- (1) Place machine in a well ventilated area on a sturdy table or bench (make sure at least 6 inches is left around each side of machine).
- (2) Lower shipping saddle by turning the two knobs on each side of the bell housing, then push them down to assure that the saddle is completely lowered.
- (3) Plug in floss machine.
- (4) Without motor running, fill floss head about 90% full with sugar. DO NOT OVER FILL! NEVER ADD SUGAR WHEN MOTOR IS RUNNING. After adding sugar, manually rotate head to balance.
- (5) Turn main switch and heat switch to on position.
- (6) Turn heat control knob clockwise to maximum setting to produce the fastest possible warm up.
- (7) In a few seconds the machine will begin to make floss, if the machine starts to smoke, simply turn the heat control knob counterclockwise to eliminate the smoking.

CAUTION: IF YOU SMELL BURNING SUGAR OR SEE SMOKE,
REDUCE THE HEAT.

- (8) Once an ideal setting is found for the HEAT CONTROL, you should be able to operate near this position each time.

Page 2
Econo Floss Machine

Making Floss:

- (1) Twist floss cone from stack of cones.
- (2) Hold an inch or two of the pointed end of the between your two fingers and your thumb.
- (3) With a light flicking action, break the web of that is building up in the pan.
- (4) Lift up the cone with the ring of floss attached and rotating the cone, wind the floss onto it.

DO NOT ROLL FLOSS ONTO THE CONE WHILE IT IS INSIDE PAN - THIS WILL PACK THE FLOSS ONTO THE CONE.

FOR ADDITIONAL HELP, SEE ATTACHED PROCEDURE SHEETS


- (5) When stopping at end of day or for any prolonged period of time, run all sugar out of the floss head by turning the heat to the maximum setting for about one minute.

We pride ourselves in the quality of our rental equipment and the cleanliness of it when it leaves our warehouse. For some reason you are not satisfied when you receive machine, please call our office immediately.

Good luck with the use of this Floss Machine and we hope you will rent from us again.


FLOSS MAKING PROCEDURE

ADD FLOSSUGAR ONLY WHILE MOTOR IS NOT RUNNING
WHENEVER YOU ADD FLOSSUGAR TO THE HEAD,ALW
FILL HEAD ABOUT 90% FULL. HAND ROTATE HEAD T
SPREAD FLOSSUGAR EVENLY. THIS WILL ELIMINATE
EXCESSIVE HEAD VIBRATION. DO NOT OVERFIL



GRIP--ROTATION

"WIND THE WEB OF
SUGAR ONTO THE CONE"





Grip cone as shown.

Break into web of floss with cone.


Lift web of floss from pan and roll onto cone.

REMEMBER! Let the machine do the work.



KEEP HANDS AWAY FROM SPINNING HEAD!



3



5



7