


ESPRESSO  
CHIZ

# COFFEE MAKERS

## OPERATING INSTRUCTIONS:

1. Fill coffee pot with COLD water to a desired amount
2. Add coffee to a basket (see equivalent below)
3. Plug coffee pot into a standard electrical outlet
4. When coffee has finished brewing, remove basket, the pot will keep the coffee hot



## CLEANING INSTRUCTIONS:

Rinse out coffee pot and basket before returning.  
NEVER IMMERSE COFFEE POT IN WATER

## BREWING TIME:

It takes approximately 1/2 hours to brew coffee in 30 to 60 cup urn  
1 hour in 90 to 100 cup urn

## COFFEE EQUIVALENTS

| <u>Number of cups</u> | <u>Coffee measure</u> |
|-----------------------|-----------------------|
| 30                    | 2 cups                |
| 60 to 80              | 3 1/2 cups            |
| 90 to 100             | 6 cups                |

One pound of coffee is equal to approximately 4 3/4 cups ground coffee

REMEMBER. You are renting this equipment. Be sure you are aware of the terms of your rental contract. Always return your coffee pot clean to avoid additional cleaning charges.